

Everest Collection Care & Maintenance

Australian Select Timbers[®] brings you stylish, sustainable, sophisticated and simply beautiful floors but taking care of them to preserve their magnificent finish and quality presence is a must. By following a few simple care and maintenance guidelines your floor will continue to be a thing of beauty for years to come.

Preventative Maintenance

- Installing good quality mats inside and outside of external doors to trap grit and remove moisture from shoes is a sensible precaution and will reduce the possibility of scratches.
- In high traffic areas or areas where spillage may occur the use of mats is recommended to give added protection.
- All furniture should have felt pads fitted to the base of legs or on other areas in contact with the floor to avoid scratches. On heavy furniture felt backed castors can be used if required.
- Avoid using wheeled chairs i.e. office furniture or ensure that a large good quality office mat is used to prevent indentations in the timber.
- Rubber based items e.g. the backing for matting, castors under furniture and rubber tipped furniture feet should not be in direct contact with the floor.
- Keep pet's nails trimmed to protect the floor from scratches.
- All timber reacts when exposed to direct sunlight and this may cause colour changes or fading. Curtains, blinds or UV resistant films on windows should be considered to reduce the exposure to direct sunlight and protect the flooring. Furniture and rugs should be moved occasionally so that the effect of sunlight on the floor is uniform.
- Any liquids spilt on the floor should be wiped up immediately.
- Maintaining the temperature and humidity within a reasonably consistent range will keep the floor stable.

Wax Oil Re-Oiling Maintenance

We recommend all GrandOak Everest Collection products with wax oil finish need to be re-oiled and maintained every 12 months for residential use and 6 months for commercial use to keep the floor fresh and ensure the warranty won't be compromised.

Please follow up our instructions carefully and always to contact the manufacturer if not sure. We recommend using Woca Hard Wax Oil as it was original coated on GrandOak Everest Collection floorboards.

- The floor must be cleaned with professional flooring cleaning products. Please refer to our cleaning guides for more information.
- Shake oil containers well before and during use.
- Apply the first coat thinly, thorough and evenly along wood grain using a microfibre roller or and spread well. Remove surplus. Approx 24m² with one coat per litre according to the coating manufacturer guidelines.

- Leave the oil to be absorbed and allow for good ventilation whilst drying for 8-10 hours. Low temperatures and/or higher air humidity can increase the drying time.
- When the Work in small areas one step at a time until the floor is finished.
- If necessary a second coat be applied same as per the first coat.
- After the coat fully dries, the floor needs to be fully cleaned with professional flooring cleaning products.

Cleaning

- Dry cleaning of the floor should be carried out regularly to remove loose dirt, grit and dust. Use a Dusting pad or soft broom. If vacuum cleaning, the cleaning head must have a soft brush so as to not damage the floor.
- Use a Spray Mop with Wood Floor Cleaner to clean the floor surface when required; dry clean the floor first. Do not 'wet' mop the floor anytime as excessive amounts of water may cause damage.

Avoid the following:

- Indentation from stilettos or spiked heels.
- Pulling or pushing furniture or other objects across the floor.
- Avoid using a steam mop, abrasive cleaning materials or harsh detergents / household cleaners on the floor. Using these cleaning methods / materials will harm the surface of the floor and may cause physical damage to the boards.
- Do not use solvents of any kind to clean the floor. Methylated Spirits, Turpentine or similar materials will damage the floor surface.

Important Note: All GrandOak Everest Collection products with wax oil finish need to be re-oiled and maintained every 6 months for commercial use and 12 months for domestic use. This will refresh your floor and ensure that the warranty will not be compromised.